



Package Contents:

Fitness Mat
 Jeli Sleeve
 Travel Bag
 Power Fit
 Remote Holsters
 Sweat Bands
 Textured Foot Socks

USING THE FITNESS MAT:

1. Unroll the Fitness Mat and lay on a flat surface.
2. Start workout.

Note: You can also use the Fitness Mat for your other exercises, such as Pilates and Yoga.

USING THE JELI SLEEVE:

To Put On:

1. Lay the Wii Balance Board face up on a flat surface.
2. Lift one side of the Wii Fit Balance Board
3. Slide the Jeli Sleeve over the lifted side of the Wii Fit Balance Board making sure the open slots on the Jeli Sleeve go evenly over the "legs" located on the bottom of the Wii Fit Balance Board. Make sure the silicone pegs on the Jeli Sleeve go flush into the slots located next to the "legs" on the Wii Fit Balance Board. Follow the same procedure on the other side.

To Take Off:

1. Lay the Wii Balance Board face up on a flat surface.
2. Lift one side of the Wii Fit Balance Board
3. From the bottom, lift the Jeli Sleeve from one end removing all of the silicone pegs from the slots. Lift the Jeli Sleeve over the Wii Fit Board legs and slide it up and over the side of the Wii Fit Balance Board
4. Follow the same procedure on the other sides and remove the Jeli Sleeve from the Wii Fit Balance Board.

USING THE TRAVEL BAG:

1. Lay the Travel Bag on a flat surface.
2. Unzip the Travel Bag by pulling the zippers to the far end of the bag until the zippers cannot go any further and the bag is completely open and unzipped.
3. Lift up on end of the Travel Bag and slide in the Wii Balance Board.
4. Close the Travel Bag and zip it back to where the bag is completely closed.

USING THE POWER FIT:

1. Plug the USB power cable into an available USB port on your Wii console or any other device that has a powered USB port.
2. Remove the door from the Wii Balance Board and insert the Power Fit with the "teeth" end going in first. Confirm the Power Fit is securely attached to the Wii Balance Board.
3. To remove, press the release tab and lift the Power Fit up and out of the Wii Balance Board.

TROUBLESHOOTING:

Problem: The zipper does not work properly.

Solution: Make sure that there aren't any broken parts or debris hindering proper movement on the zipper.

Problem: The Neo Fit does not go on properly to the Wii Balance Board.

Solution: Make sure the elastic straps aren't torn. Make sure there aren't any broken parts or anything else hindering proper insertion on the Wii Balance Board.

Problem: The Power Fit is not powering my Wii Balance Board.

Solution: Make sure that the Power Fit is inserted into the Wii Balance Board properly and securely. Make sure that there is no debris hindering proper placement of the Power Fit.

